



Operating Instructions for Snow Cone Machine

1. Fill the hopper to within 1" of the top with ice cubes or block ice (block ice pieces should be no larger than 3-4")
 2. The larger the pieces of ice the better the snow
 3. Switch the motor on & wait until it comes to full speed (1-2 minutes)
 4. Push the handle down against the ice applying firm and even pressure
 5. Relieve the pressure 2-3 times in a cycle to allow ice to settle against the shaver head
-
- Never allow foreign objects to come into contact with the shaver head, damage may occur
 - All equipment is tested before delivery but should be rechecked at least 6 hours prior to use in case of malfunction
 - Equipment must be kept dry and away from moisture
 - When using multiple pieces of electrical equipment, do not overload the circuit, this may cause the equipment to fail